





THE MIZNER CHAIR




21" width




24" width




Dual 24" connected seats for 48" loveseat




21" x 41" MIZNER




24" x 41" MIZNER




60




STRAIGHT & WEDGE ARMS




TOP VIEW OF CONSOLE



Row of 3- 24" width




ARM




SMALL OTTOMAN



SHARK REMOVABLE ARM




24" x 41" MIZNER CHAISE



36" x 41" MIZNER CHAISE

CHAISE



Angled Row of 4- 24" width

We recommend that the Minimum distance between rows is 84" from back of chair to back of chair

Average Weight Chair: 100 lbs Arm: 25 lbs Console: 35 lbs